

Item	Description	Quantity
	<i>For BRKT-As030</i>	
1.	<i>Bracket Universal L-Shaped DC Die Cast</i>	1
2.	<i>M6 x 30mm Bolt SS</i>	3
3.	<i>M6 nylock nut ss</i>	3
4.	<i>M6 flat washer ss)</i>	6

Installation Instructions

Pole Mounting

1. *Attach the universal L bracket to the antenna by means of the three M6 bolts,six M6 flat washers and three M6 nylock nuts provided.*



2. *Attach the assembly to a mast (diameter 32-50mm) using the two Econo-bracket assembly as shown in the figure below*

