SYNERGY 21

Camping Lamp



S21-LED-JT240023

User Manual

Please read this instruction carefully before using the product and keep it properly.

0

Product bottom can he mannetized on the

metal surface

Functional

SOS Mode

Indicator

Welcome to us Thank you for choosing our Camping Lamp

Camping Lamp is suitable for various outdoor activities

Concise appearance, beautiful and warm lights, simple operation. The product brings user a new

Atmosphere light mode, User can easily adjust the brightness and color temperature of product. Turn on the candle light, the product looks like a candle.

The candle light flashes like a breathing solar eclipse, warm and romantic. Help users fall asleep

Have a nice time and to find more different usage

⚠ Safety Tips

- Before use, please check if the product is fully charged to avoid running out of power halfway and unable to use.
- When power is low please charge as soon as possible, low power state for a long time shelved may cause the core to
- Use a 5V/2A charger to charge the appliance, and other chargers may cause charging to be slow or not charged. Do not disassemble or change the product structure to prevent electric shock or fire
- Do not charge when the charging interface is wet or visibly damp to avoid electric shock danger, keep the charging interface

1. Brightness and colour temperature of camping lamp easily adjust.

211/

Standard charging is 5V/2A

1600K~5500K

battery temperature decreases

1.5 hours

- 2. Long press to enter into the SOS distress signal mode
- 3. Light shakes like a candle

Product Mode

Battery Capacity

Maximum Powe

Colour temperature

Charging Time

Using Time

Can't turn or

Prod Basic Parameters Lithium-ion battery 3.7V/900mAh



a. Button

d. Top Cover

4. Candle lamp breathing to help sleep. 5. Breathing aperture looks like solar eclipse 6. Product bottom with magnetic attraction function

7. Supports 2A fast charging and fully charging takes only 1.5 hours

Synergy 21 LED outdoor IPX5 Teelicht dimmbar

b. Candle Light

e. Product Bottom

c. Ambiance Light

f. USB Connector

Germering, 07th of May, 2024

S21-LED-JT240023 The safety advice in the documentation accompanying the products



EMC 2014/30/EU

by the CE sign on the device. This equipment meets the following conformance standards:

RoHS 2011/65/EU EN IEC 55015:2019+A11:2020 EN IEC 61000-3-2:2019+A1:2021 EN IEC 61000-3-3:2023+A1:2019 EN 61347-2-11:2001+A1:2019

2015/863/FU EN 61547:2023 EN 60598-2-4:2018 EN IEC 60598-1:2021

shall be obeyed. The conformity to the above directive is indicated

IVD 2014/35/EII

This equipment is intended to be operated in all countries

This declaration is issued under the sole responsibility of the manufacturer:

ALLNET GmbH Computersysteme

Maistraße 2 82110 Germerina

Germering, 07.05.2024

Germany









pattern of three long and three short flashes. Tap the button to exit.

Red led indicator flash for low power

Green led indicator flash for charging

Green led indicator on for fully charged

Keep USB connector

dry before charging

When the light is turned off, long press the button for 3 seconds to enter into the SOS distress signal mode. At this time, the LED light will cycle flashing in a

Environmentally Friendly Use of the Term
The logo identified on the product body identifies environmental protection for a period of 10 years.

The environmental protection period of electrical and electronic products refers to the period of time when the toxic and harmful substances or elements contained in electrical and electronic products will not leak to the outside world or suddenly mutate, and the users of electrical and electronic products will not cause serious pollution to the nment or serious damage to human body or property when using electrical and electronic products.

Can't charge the battery The charging indicator light is not on. Please check if the charger is properly plugged in

The light shuts down after running for a while. Please restart it or check if there is enough battery

The battery temperature is too bigh, temperature protection is activated. Please restart after the

If the above situations are excluded, it may be a machine failure. Please contact the seller for after

During the environmental protection period, please use this product in accordance with the instructions for use The Regulations on the Recycling and Handling of Waste Electrical and Electronic Products provide a suggestive: In order to better care for and protect the earth, when users no longer need this product or product life is terminated, please comply with the national waste electrical and electronic products recycling and treatment of

relevant laws and regulations, it will be handed over to the local manufacturers with nationally recognized recycling qualifications for processing