


Product Description

There is an intelligent far-infrared sensing device under the cabinet lamp, which has fast response without delay. Suitable for cabinets, wardrobes, wine cabinets, aisles, corridors and other places Optical diffuser Optical light guide plate Reflective paper Strong magnet Large capacity battery Inductive senso Light color adjustment button

Induction Range

The automatic sensing range is 16.4FT-19.6FT/120° 20 seconds no action automatically shut down



Parameter

20cm/30cm/40cm/60cm

1W/1.5W/2W/2.5W

3.7V

0.2W

44LED/78LED/100LED/155LED

1000mA 1000mA/1500mA/2200mA

20s

Aluminum + ABS

100/150/200/250LM

5000 hours

16 4-19 6FT 120°

3000k/4000k/6500k

Product size

Power

Power supply

Lamp beads

Number of lamp beads

Charging current

Lithium battery capacity Default induction time

Material

Lumens

Service life

Sensing distance and angle

Color temperature



the first group of indicator lights () will light up,

Light color brightness adustment button:

3000k-4000k-6500k

and enter the human body induction + light control mode

Mode 2:Short press once, the second group of indicator

lights () lights up, enter the human body induction mode

dicator lights ($\dot{\circlearrowleft}$) lights up, entering the normally open mode

Mode 3: Short press for the second time, the third group of

Short press to switch the color temperature, respectively

• Long press to realize 0%-100% stepless dimming

Installation instructions Stick the lamp directly on the iron surface

Mode adjustment buttor

Charging interface

Ferrous surface

It can be installed on the non-ferrous surface by pasting iron sheet and cooperating with the magnet of the lamp. Before installation, ensure that the installation surface is

clean and flat

Adsorb the pasted iron sheet to the back of the lamp

Non ferrous surface

Tear off the sticker on the back of the iron sheet and install the lamp where needed

4	Mhan using it for the first time	places fully shares it first
- 1	. When using it for the first time.	please fully charge it first

- 2. If it is not used for a long time, it is recommended to charge it is once every 3 months for the maintenance of the built-in
- lithium battery 3. The hand-scanning sensor cannot be covered by other items. When cleaning the surface of the lamp, you need to wipe it with a soft face sponge, and avoiding contact with the corrosive
- 4 .Do not install in humid, high-temperature places, or vents.
- so as not to affect normal use 5. Do not disassemble the product without permission